

PART NUMBER

**K-30-009**

**Combo Kits**

**PRODUCT INFORMATION**



**PRODUCT LINE**  
Combo Kits

**COLOR**  
Black & Yellow

**VARIATION**  
Front & Rear

**BOX INFORMATION**

**SHIPPING DIMENSIONS**



**BOX DESCRIPTION**

Medium 2 Pack SumoSpring Box

**BOX NUMBER**  
512513

**TAPE MACHINE POSITION**  
#22 // 20" (50.80cm)

**BILL OF MATERIALS**

Item	Part #	Discription	QTY
A	CCS-1195	Coil SumoSprings Kit	1
B	SSR-313-54	SumoSprings Rear Kit	1
C	512513	Medium 2 Pack SumoSpring Box	1

**COIL SUMOSPRINGS**



**A** **COIL SUMOSPRINGS**  
CSS-1195

**SUMOSPRINGS REAR**



**B** **SUMOSPRINGS REAR**  
SSR-313-54

**PACKING INSTRUCTIONS**

1. Locate the preassembled kits needed to build the combo kit as listed in the Bill of Materials section.
2. Start by building the kit box according to the Box Guide.
3. Place the kits in the box with the side of each box facing up (refer to diagram below). With the kit boxes in the bottom of the combo kit box, using the filler paper machine, release enough paper to fill the space at the top of the box. The SumoSprings kits should fit snug with little to no movement.



4. Close the top of the box by completing the steps referenced in the Box Guide.

5. Using the scanner (refer to scanner instructions) print out a label.

6. Position label horizontally, on the left side of the end of the box with the SuperSprings International logo side to the left (refer to Completed Kit Diagram).

7. Place the finished kit in the applicable bin.

**COMPLETED KIT**



**COMPLETED KIT WEIGHT**  
8lbs (3.63 kg.)